













ASSEMBLY INSTRUCTION

| | | | | | | | |
|--|---|---|---|---|---|--|---|
| A  x1 | B  x1 | C  x1 | D  x1 | E  x1 | F  M6x40 x8 | G  M6 x4 | H  x1 |
| Extra Parts  M6x40 x1 | Extra Parts  M6 x1 | | | | | | |


STEP 1



STEP 2



STEP 3



STEP 4



Please ensure that when returning these goods, each part of the original packaging is reused. This is essential to prevent damage. Your careful handling of the packaging contributes to a safe return shipment and ensures that the furniture arrives in optimal condition with us. Thank you for your cooperation!