




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR 2S.OTM

M8X40



B1-4




B2-12

M6X30



B3-16



B4-8

M8X70



B5-8



B6-2



B7-8

US5X40



B8-16

h-25



E1-16

5



D1 -x1



C1-2

C2-6



C2-6


C3-2




C3-2



30 min



2S.OTM





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



2/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR 2S.OTM

M8X40



B1-4



B2-12



B3-16



B4-8



B5-8




B6-2



B7-8



B8-16



E1-16



D1-x1







C1-2



C2-6



C3-2





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató




3/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR 2S.OTM

M8X40



B1-4




B2-12

M6X30



B3-16



B4-8

M8X70



B5-8



B6-2



B7-8

US5X40



B8-16

h-25




E1-16

5



D1 -x1


C1-2



C2-6




C3-2





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató




4/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR 2S.OTM


M8X40




B1-4



B2-12



B3-16



B4-8



B5-8



B6-2



B7-8



B8-16



E1-16



D1-x1








C1-2





C2-6



C3-2




Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név	M8X40 B1-4	 B2-12	M6X30 B3-16	 B4-8	M8X70 B5-8	 B6-2
SALVADOR 2S.OTM	US5X40 B8-16	h-25 E1-16	5 D1 -x1	 C1-2	 C2-6	 C3-2
 	 B7-8					




Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

B1		E1		L1		
B2		C1		L2		
B3		C2		L3		
B4		C3		L4		
B5				L5		
B6				L6		
B7						
B8						
D1						





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



6/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR OTM.2S

M8X40



B1-4




B2-12

M6X30



B3-16



B4-8

M8X70



B5-8



B6-2



B7-8

US5X40



B8-16

h-25



E1-16

5



D1 -x1

C1-2





C2-6




C3-2



30 min



2S.OTM





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



7/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR OTM.2S

M8X40



B1-4




B2-12

M6X30



B3-16



B4-8

M8X70



B5-8



B6-2



B7-8

US5X40



B8-16

h-25



E1-16

5



D1 -x1

C1-2



C1-2

C2-6







C2-6

C3-2



C3-2




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató

8/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név	M8X40		M6X30		M8X70	
	B1-4	B2-12	B3-16	B4-8	B5-8	B6-2
		US5X40	h-25			
	B7-8	B8-16	E1-16	D1-x1	C1-2	C2-6
<div> </div>						



D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



9/10

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR OTM.2S

M8X40



B1-4



B2-12

M6X30



B3-16



B4-8

M8X70



B5-8



B6-2



B7-8

US5X40



B8-16

h-25



E1-16

5



D1-x1









C1-2





C2-6



C3-2





Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

SALVADOR OTM.2S

M8X40



M6X30

[illegible]

M8X70

[illegible]

US5X40




h-25

5 

1	
---	--



7

[illegible]

Service-Dienstverlening-Serwis-Servis-Сервисная Служба-Assistenza-Szerviz

B1		E1		L1		
B2		E2		L2		
B3		E3		L3		
B4		C1		L4		
B5				L5		
B6				L6		
B7						
B8						
D1						

