ASSEMBLY INSTRUCTIONS

1



2



3



Ax1



Bx1



Cx1



Dx4

Ex1