

Montageanleitung :


Assembly instruction

Rollcontainer
VAC30/**/**
VAC20/**/**

MO_CAC.pdf
Stand: 12/2020




AC30



AC20

4x (A)  je 2x 500425	4x (B)  500213	(C)  4x27mm 500227 (D) (SG) 104877	(C)  4x27mm 500227 (D) (RE) 500433	(C)  M4x25mm 500176 (D) (CE) 103964	(C)  M4x23mm 500322 (D) (BM) 103956	(C)  M4x25mm 500176 (D) (BS) 588448
---	---	--	--	--	---	---

1




Sie benötigen:
SW 13

4x (A)


4x (B)


2




4 - 5 x (D)

je 2 x (C)

(C)


(D)


3



* Frontblende ausrichten

