


9171-1

Ver.2.0 13-09-2021





SAFETY INFORMATION: (Please retain for future reference)

- · Always turn off the mains supply before commencing the installation of this fitting.
- This is a Class 1 product and requires an Earth connection 230 (240) Volts 50Hz AC.

LIVE - Possible colours: Red or (Brown)

EARTH - Un-sleeved copper or (Green / Yellow)

NEUTRAL - Possible colours: Black or (Blue)

Ath Block for "Loop In" system (if required)

- This product must be installed in accordance with the national building and wiring regulations, if in doubt consult a qualified electrician.
- We do not recommend any modifications of the fitting, (*with the exception of cable and chain shortening) as this may invalidate the warranty and render the fitting unsafe.
- This fitting is suitable for installation in Indoor locations only .
- Do not mount the fitting in a damp atmosphere.
- Ensure sufficient access to the fitting to enable safe maintenance.
- Take care when compressing the springs clips inwards to fit the glass shade hat you do not trap fingers.

LAMP INFORMATION:

- Do not exceed the maximum wattage and bulb type stated on the lamp holder.
- The fitting is compatible with energy efficient LED lamps in their available maximum wattage or equivalent wattage

DIMMING:

This fitting maybe dimmed when using a suitable wall dimmer ,when using dimmable LED lamps the dimmer must be capable of dimming this type of lamp.

ADDITIONAL INFORMATION:

• If the height of the fitting requires shortening we recommend that the removal of any supply cable that may need to be cut to a shorter length is done by a qualified electrician (Remember to mark clear cable with Live, Neutral and Earth prior to removing from the terminal block). The length of the supply cable CANNOT be increased.

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do no use any abrasive cloths or cleaners as this may damage the product

This symbol on the product indicates that this product must not be disposed of with your normal household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of wasted electrical and electronic equipment. For more information about recycling please contact your local

council or your household waste disposal service or the shop where you purchased the product.