

Servicekarte / Service card

Modelname / Model name WZ-0663 Vitrine II, Wildeiche massiv geölt / Display cabinet II, solid wild oak, oiled	Artikelnummer / Article No. 1013355	Ausführung / Design Eiche / oak																								
<p>The diagram illustrates the exploded view of the WZ-0663 display cabinet. It shows the left side panel (D64) and right side panel (D70) standing upright. Inside, there are four shelves: a top shelf (D15) holding a 10 KG weight, a middle shelf (D36) holding a 10 KG weight, a bottom shelf (D38) holding a 25 KG weight, and a bottom-most shelf (D14) holding a 40 KG weight. A back panel (D65) is shown leaning against the sides. To the right, two doors (D71 and D72) are shown standing vertically.</p>																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tbody> <tr> <td style="width: 12.5%; text-align: center; padding: 5px;"> V 1X </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> B6 1X 8X40 </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> O1 1X 5X70 </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> P7 1X 4,2X13 </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> H1 8X </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> P2 32X 4,2X41 </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> B4 24X 8X30 </td> <td style="width: 12.5%; text-align: center; padding: 5px;"> H12 16X </td> </tr> <tr> <td style="text-align: center; padding: 5px;"> P5 16X 4,2X19 </td> <td style="text-align: center; padding: 5px;"> F4 6X </td> <td style="text-align: center; padding: 5px;"> S11 4X </td> <td style="text-align: center; padding: 5px;"> S12 4X </td> <td style="text-align: center; padding: 5px;"> O9 32X 4X16 </td> <td style="text-align: center; padding: 5px;"> H 4X </td> <td style="text-align: center; padding: 5px;"> O14 28X 3,5X16 </td> <td style="text-align: center; padding: 5px;"> T1 12X </td> </tr> <tr> <td style="text-align: center; padding: 5px;"> E4 18X </td> <td style="text-align: center; padding: 5px;"> E1 18X </td> <td style="text-align: center; padding: 5px;"> O13 4X 3,5X20 </td> <td colspan="5"></td> </tr> </tbody> </table>			 V 1X	 B6 1X 8X40	 O1 1X 5X70	 P7 1X 4,2X13	 H1 8X	 P2 32X 4,2X41	 B4 24X 8X30	 H12 16X	 P5 16X 4,2X19	 F4 6X	 S11 4X	 S12 4X	 O9 32X 4X16	 H 4X	 O14 28X 3,5X16	 T1 12X	 E4 18X	 E1 18X	 O13 4X 3,5X20					
 V 1X	 B6 1X 8X40	 O1 1X 5X70	 P7 1X 4,2X13	 H1 8X	 P2 32X 4,2X41	 B4 24X 8X30	 H12 16X																			
 P5 16X 4,2X19	 F4 6X	 S11 4X	 S12 4X	 O9 32X 4X16	 H 4X	 O14 28X 3,5X16	 T1 12X																			
 E4 18X	 E1 18X	 O13 4X 3,5X20																								
Grund der Beanstandung: <i>reason for complaint:</i> _____																										
Name: _____ <i>name:</i> _____																										
Strasse: _____ <i>street:</i> _____																										
Postleitzahl: _____ <i>postal code:</i> _____																										
Telefonnummer: _____ <i>telephone number:</i> _____																										
Ort: _____ <i>place:</i> _____																										
HausNr.: _____ <i>house number:</i> _____																										

DE: Sehr geehrter Kunde, Sehr geehrte Kundin!

Fehlt Ihnen ein **Beschlagteil** oder ist es Defekt? Kein Problem! Nutzen Sie unsere Servicekarte!

Unser Direkt-Bestellservice für fehlende/defekte Beschlagteile:

Kontaktieren Sie uns telefonisch unter Tel. **+499503/5033-114** oder senden Sie uns eine E-Mail an kundendienst@3s-frankenmoebel.de. Bitte geben Sie dabei folgende Pflicht-Informationen an: -> Auftragsnummer, Artikelnummer, Nummer des Beschlagteils, fehlende/defekte Menge, und den Grund der Beanstandung, ob es sich um ein defektes oder fehlendes Beschlagteil handelt. Tragen Sie die benötigte Menge ein. Mailen Sie uns die vollständig ausgefüllte Servicekarte zu, um die Bearbeitung zu ermöglichen. Für **andere** Beanstandungen / Beschädigungen an Ihrem Möbelstück wenden Sie sich bitte **direkt an Ihr Möbelhaus**.

EN: Dear customer!

Are you missing a **fitting part** or is it defective? No problem! Use our service card!










Our direct ordering service for missing/defective fitting parts:






Contact us by telephone on **+499503/5033-114** or send us an e-mail to kundendienst@3s-frankenmoebel.de.



Please include the following mandatory information: -> Order number, article number, number of the fitting part, missing/defective quantity, and the reason for the complaint, whether it is a defective or missing fitting part. Enter the required quantity.

Mail us the completed service card to enable processing.


For **other** complaints/damage to your furniture, please **contact your furniture store directly**.












1




2




3




A




B



C



B



A



C