



IMPORTANT
TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly.
Bulbs are not included

1. Screw threaded pipe securely into a finished ceiling then slip the same threaded pipe through cap and center plate. Lock all together by fastening with another finished plate above.
2. This fixture can be mounted onto ceiling either as chain hung or flush mount:

CHAIN HUNG INSTALLATION—Fig. 1:

- A. Take fixture wire (with plastic insulation) and ground wire and thread through fixture loop. Then install loop onto threaded pipe located at top of fixture.
- B. This fixture is supplied with 2 chain links. These links are opened and closed by twisting cylinder on chain link. One threaded chain link should be installed to canopy loop and the other should be installed to fixture loop. The standard chain should be installed between these 2 threaded chain links.
- C. Determine the desired length of chain to hang. Remove any unwanted links with chain pliers.
- D. Take wire and leave through above chain link then thread through center hole in canopy cap.

FLUSH MOUNT INSTALLATION—Fig. 2:

- A. Remove and discard canopy cap and threaded pipe from fixture plate.
 - B. Thread ground wire and fixture wire through fixture plate, lock washer, and hex nut. Lock all together on top of fixture by tightening hex nut onto threaded pipe.
3. Cut excess wires leaving only 6" (15cm) length of wire above canopy.
 4. Follow enclosed "Installation Instructions" for electrical and fixture installation to ceiling.
NOTE: Before starting wire connection, enlist a professional to support the fixture, or make a hook from a wire coat hanger and temporarily suspend the fixture from mounting plate.
 5. Place shade over threaded socket then spacer tube and secure with counter ring, using supplied wrench.
 6. Install light bulbs (not included) in the location at socket area for type and maximum allowed wattage.